

## List of ITL Manufacturers preset for Plunge

NAME	ID#	SERIES	PLUNGE
ABUS/03	4	5525	FIRST
ALFA ROMEO/01	12	1100-1789 3100-3789 5100-5789 DOOR & TRUNK 76-80	FIRST
ALFA ROMEO/05	18	AL0001-1274, MILANO 1987 UP	FIRST
AMERICAN/01 (JUNKUNC)	26	PADLOCK	FIRST
ARROW(PLYMOUTH)/01	31	H 0001-5143	FIRST
ARROW(PLYMOUTH)/02	32	SL 5001-7000	FIRST
AUDI/01	42	11X11-91X91 11W11-91W91	FIRST
AUDI/03	356	AH AN HV N NV VB 1-854 2001-2830 4001-5151 7101-8154 Enter 2nd 4th 6th Sp. twice	FIRST
AUDI/04	357	AH AN HV N NV VB 1001-1918 3001-3890 6001-7086 8201-9282	FIRST
AUSTRALIAN GENERAL MOTORS	901		FIRST
BMW/05A	62	HB,NB 10,000-20,000 11 WAFER 1984+	FIRST
BRITISH '78-'89	625	AK1-AK1000	FIRST
BRITISH AUTO '70'S	627	D1-D650	FIRST
BRITISH AUTO '80-'83	626	BL1001-BL2000	FIRST
BRITISH LEYLAND/01	75	BL1001-2000 RO1001-2000 W1001-2000 CRICKET SL 5001-7000	FIRST
BRITISH LEYLAND/03	77	2001-3000 & 3001-4949	FIRST
BYRNE & DAVIS/6	909	19001-19053 19101-19200 19201-19290 19301-19400	FIRST
CAPRI/03	82	TC 1-1000	FIRST
CAPRI/04	83	AK,JC ROVER AK MID 70'S *CAUTION* ENTER 2ND,4TH & 7TH CUTS TWICE	FIRST
CHEVROLET/02	285	CHEVY NOVA(TOYOTA) 1986+R001-R6HR S001-S69S	FIRST
CHRYSLER/01	194	CV 1959 - 1967 WAFER TRUNK & GLOVE ,CV1-1500	FIRST
CITROEN/01	101	A,B,E,T,U,V,W,X,Y,Z 11111-77777 DIRECT DIGIT	FIRST
COLT (DODGE)/01	31	H 0001-5143	FIRST
COLT (DODGE)/02	32	SL 5001-7000	FIRST
CRICKET '70'S	629	SL5001-7000	FIRST
CRICKET(CHRYSLER)	31	H 0001-5143	FIRST
DAEWOO	53	J0001-1200, T001-1200, V0001-1200	FIRST
DAEWOO	911		FIRST
DAIHATSU	196	D0001-2000	FIRST
DODGE SPRINTER	303	NF0001-1200	FIRST
EAGLE/07	156	WAFER A36A	FIRST
FIESTA	82	TC 1-1000	FIRST
GENERAL MOTORS/01	194	1935-1965	FIRST
GENERAL MOTORS/02	195	1965 AND UP	FIRST
GENERAL MOTORS/06	387	S/S VATS ONLY ( Slide key until vats resistor touches vice edge )	FIRST
GEO PRIZM/01	196	G001-G7NP	FIRST
GEO TRACKER	507	18100-19299	FIRST
GEO-METRO/STORM	196	N5001-7000	FIRST
GLIDEROLL	915	19401-19420	FIRST
GM 72 LUV TRUCK	421	B5001-6000	FIRST
GM CADILLAC ALLANTE	79	VA DOOR & TRUNK 1987+	FIRST
GM CADILLAC CATERA	349	S0001-2000	FIRST
GM PONTIAC LEMANS	349	S4001-5200 1988-93	FIRST
HARLEY DAVIDSON/02	422	001-200 89-94	FIRST
HONDA/02	77	2001-4949 CIVIC IGN 70 - 76	FIRST
HONDA/03	206	111111-444444 DOOR & TRUNK 73-76 DIRECT DIGIT / CUT TIP TO BOW	FIRST
HONDA/04	205	1001-1700 2001-2700	FIRST
HONDA/05	211	3001-4481 ACCORD1982+, ACURA 86+	FIRST
HONDA/06	510	5001-8442, 1988+, ACURA 1990+	FIRST
HONDA/07	205	C&D 00-99	FIRST
HONDA/08	205	A&B 00-99	FIRST
HONDA/10	551	101-120, 201-220, 301-320, 401-420, 501-520, 601-620, 701-720, 810-820	FIRST

## List of ITL Manufacturers preset for Plunge

NAME	ID#	SERIES	PLUNGE
HONDA/11	551	121-140, 221-240, 321-340, 421-440, 521-540, 621-640, 721-740, 821-840	FIRST
HONDA/CYCLE/02	209	101-820 121-840 1977+	FIRST
HONDA/CYCLE/04	213	00007-99998 DIR DIG MID 70'S 0/5,4/9,3/8,2/7 = 1,2,3,4	FIRST
HONDA/CYCLE/05	205	A00-99, B 00-99 1983+ USE LAST 3 NUMBERS OF CODE	FIRST
HONDA/CYCLE/07	205	C00-C99, D00-D99	FIRST
HONDA/CYCLE/08	205	J, K, L, M, N, P, Q, R, S, T, 00-99, U00-39	FIRST
HYUNDAI/01	285	H0001-5143 Pony 85 - 87 (CANADA)	FIRST
HYUNDAI/02	231	X0001-1000 Excel 86 - 89	FIRST
HYUNDAI/03	231	Y10001-2000 Sonata 89 - 94	FIRST
HYUNDAI/04	231	X0001-2000 Excel 90-94 Scoupe 91- 95	FIRST
HYUNDAI/05	517	T0001-1000 Elantra 92-95	FIRST
HYUNDAI/06	517	S0001-1000 Sonata 95-99	FIRST
HYUNDAI/07	517	R0001-1000 Accent 95-99	FIRST
HYUNDAI/08	517	T0001-1000 Elantra 96-99	FIRST
HYUNDAI/09	517	S0001-1000 Tiburon 97-99	FIRST
ISUZU/01	421	B5001-6000 PICKUP, CHEVROLET LUV 1972-80	FIRST
ISUZU/02	285	C6001-7042	FIRST
ISUZU/04	507	D4001-6000 AMIGO 90-93, PICKUP 90-95, RODEO 91-95, TROOPER 93-95	FIRST
ISUZU/05	196	N5001-7000 AMIGO 88-00, RODEO 95-97, TROOPER 95-03, VEHICROSS 00-02	FIRST
ISUZU/07	138	S8001-9000 FTR DIESEL TRUCK, TILTMASER	FIRST
JAGUAR '79-'87	625	JC1-JC852	FIRST
JAGUAR/01	243	WR 1000 & XJS UP - SHORT SIDE 1 REG--.SIDE 2 BUTT AGAINST INSERT 2	FIRST
JEEP 73+	195	E trunk D ign.225-814	FIRST
JUNKUNC	26	AMERICAN LOCK	FIRST
KAWASAKI/05	256	751-795 73-78, MOVE DEPTHS ONE STEP UP WHEN USING REED CODES	FIRST
KAWASAKI/06	257	801-845 MID 70'S MOVE DEPTHS ONE STEP UP WHEN USING REED CODES	FIRST
KAWASAKI/08	259	KZ & Z 5000-5999 1979+	FIRST
KEIL/02	262	R & H	FIRST
KIA/01	520	Y7001-8200 Sephia 94-97Sportage (man trans )95-00	FIRST
KIA/02	520	Y7001-8200 Sportage ( Automatic trans) 95-00	FIRST
KIA/03	251	Y2001 - 3000 Sephia 98-02	FIRST
KIA/04	251	Y2001-3000 SPORTAGE (Auto trans) 2001+	FIRST
KIA/05	517	S0001-1000 OPTIMA 2001-4, SORENTO 2003-04	FIRST
KIA/06	517	V0001-1200 SPECTRA 2004	FIRST
KWIKSET TITAN	250	CONSTRUCTION ( Needs offset cutter )	FIRST
LAND ROVER	460	E7000-8999 DISCOVERY 94-04 RANGE ROVER 89-95	FIRST
LOWE & FLETCHER/02	280	FILE CABINET	FIRST
LOWE & FLETCHER/05	931	70001-71000	FIRST
LOWE & FLETCHER/10	938	23 SERIES & 25 SERIES	FIRST
LUV (GENERAL MOTORS)	285	C 6001-7042	FIRST
MAZDA/03	285	M 001-1100 COSMO	FIRST
MAZDA/07	297	10100-12099	FIRST
MERCEDES/03	62	HU, HY, NU, NY, 1977+	FIRST
MERKUR	307	001-1859 GERMAN FORD XR4TI SCORPIO '85+ TX SAME CUT BOTH SIDES	FIRST
MG/01	309	F11111M-F77777M DIRECT DIGIT	FIRST
MITSUBISHI/01	196	E 5001-7679 LASER, COLT, ECLIPSE, MIRAGE, GALANT, TALON, VISTA WAGON	FIRST
MITSUBISHI/02	507	30010-32009 Mirage 93+	FIRST
MITSUBISHI/05	231	X1001-2000 Precis 90-94	FIRST
MITSUBISHI/06	231	X0001-1000 Precis 87-89	FIRST
NISSAN/04	138	X0001-X8000, Y0001-Y8000, 1982+ NISSAN/DATSUN	FIRST
OPEL/03	331	C 6001-7026	FIRST
PANTERA	82	TC 1-1000	FIRST

## List of ITL Manufacturers preset for Plunge

NAME	ID#	SERIES	PLUNGE
PEUGEOT/01	340	F11111M-F77777M DIRECT DIGIT	FIRST
PEUGEOT/03	342	B,E,G,H,J DIR DIG E=0,J=1,H=2,G=3,B=4,WARD=5/SPC6	FIRST
PEUGEOT/05	344	44444-00000 DIRECT DIGIT	FIRST
RENAULT/05	366	DIRECT DIGIT E=1,D=2,C=3,G=4,B=5 DOOR&TRUNK 1977 ALSO T/V CODES	FIRST
RENAULT/06	367	LeCAR IGNITION 11111-44444 DIRECT DIGIT	FIRST
RENAULT/07	368	PEUGEOT,AMC,SIMCA E,M,N,P,R DEPTH 0=E,1=R,2=P,3=N,4=M,5/SP6=WARD	FIRST
RENAULT/08	369	1986 SLOT KEY M,N,P,R,S S=0,R=1,P=2,N=3,M=4 DIRECT DIGIT	FIRST
RENAULT/10	371	A/Z222222-999999 1976 DOOR/TRUNK DIRECT DIGIT DP9=0 DP5=1 DP2=2	FIRST
RENAULT/12	344	PEUGEOT X12 DIR DIG FROM BOW 0=0 9=1 8=2 4=3 6=4 1971-79	FIRST
ROVER	376	RO 1001-2000	FIRST
SAAB/02	383	AC1-1000 AC1001-2000	FIRST
SIMCA	396	LETTER-5 NUMBERS-LETTER DIR DIGIT	FIRST
STERLING/02	376	RO 1001-2000	FIRST
STERLING/03	83	AK1001 - 2000 DOOR/TRUNK 3500S 81-86 ENTER 2ND,4TH,7TH CUTS TWICE	FIRST
SUBARU/03	138	X8001-9000 Y8001-9000	FIRST
SUZUKI FORENZA	53	J0001-1200 2004	FIRST
SUZUKI SAMURAI	285	U3001-4000, U7001-8200 CHEVY NOVA(TOYOTA) 1986+	FIRST
SUZUKI SIDEKICK	507	18100-19299	FIRST
SUZUKI SWIFT	196	U0001-2000	FIRST
SUZUKI/CYCLE/01	406	'77/8 101-460	FIRST
SUZUKI/CYCLE/03	408	11111-44444 DIRECT DIG USING 1ST 4 #'S	FIRST
SUZUKI/CYCLE/06	214	101-499	FIRST
TAUNUS/01	82	GERMAN FORD TC 1-2000	FIRST
TOYOTA/04	285	TOYOTA D,F,K,P,R,S ISUZU/LUV C MITSUB H CHEVY SPR U HYUNDAI Z0001+	FIRST
TOYOTA/06	421	A 4441-4640 M5551-9280 N1921-2200,T3400,7899	FIRST
TOYOTA/08	196	G, P 1-2000, 1989 &UP X W0001-2000 TOYOTA CELICA SPORT COUPE 1991 MR2	FIRST
TOYOTA/10	516	N, S 0001-2000 COROLLA WAGON 93+	FIRST
TRIUMPH/05	243	WR 2001 & UP CUT SIDE 1 REG-SIDE 2 BUTT AGAINST INSERT 2	FIRST
VOLKSWAGEN/08	434	P 1-252	FIRST
VOLKSWAGEN/13	356	AH AN HV N NV VB 1-854 2001-2830 4001-5151 7101-8154	FIRST
VOLKSWAGEN/14	357	AH AN HV N NV VB 1001-1918 3001-3890 6001-7086 8201-9282	FIRST
VOLKSWAGEN/15A	446	AH AN HV NV N VB 1-9282 ENTER 2ND 4TH 5TH AND 6TH SPACES TWICE	FIRST
VOLKSWAGEN/16	449	01VA01-55VA99 FIRST 2 DIGITS=2,4,6,8 CUTS	FIRST
VOLVO/04	460	IGN 7001-9000 SEC 6250-6499	FIRST
VOLVO/05	461	1A000-5A745 IGNITION AND DOOR 1977+ **NOTE USE FLAT 8 FOR SPACES 9&10	FIRST
VOLVO/09	459	DF2001 - 4000	FIRST
CORBIN/11	120	Ward with guard lever S&G replacement	ALL
CORBIN/08	125	LEVER LOCKERS	ALL
DIEBOLD/01	139	FIXED 0.025" DROP DEPTH 1=0.370"2=0.345"	ALL
DIEBOLD/02	140	VARIABLE DROP DEPTH 1=0.375" 2=0.340"	ALL
EMHART S.D.BOX	170	11303500 Depth 9 ward depth	ALL
EMHART SYSTEM 70	162	SEE CORBIN 70 (Depth 10 is depth 5 1/2)	ALL
MEDECO/01	298	10-0-11	ALL
MEDECO/02	299	60-010 (4 DEPTHS ONLY) CAM LOCK	ALL
MEDECO/03	300	BI-AXIAL	ALL
MEDECO/04	301	EXTENDED SPACES FOR MEDECO/3	ALL
MEDECO/05	302	LEVEL II HALF STEP DROP USE MEDECO PIN KIT # K-10 CLEAN BURRS	ALL
MEDECO/06	492	CAM LOCK BIAXIAL	ALL
SARGENT & GREENLEAF/02	385	4231, 44XX SAFE DEP. Cuts 7&8 are throat cut	ALL
SARGENT & GREENLEAF/03	386	41XX, 45XX SAFE DEP. Cuts 8&9 are throat cut	ALL